

Hi!

Need help with the **Oven**?



1.

General Instructions



2.

How to cook a frozen **pizza**?



3.

How to microwave **baby food**?



4.

How to **defrost** food?



5.

General **programs** by type of food



Step 1 Push the right button to turn the oven on



Step 2 By default, the first function displayed after turning the oven on is the microwave. Tilt the right button to choose your preferable function.

Step 3 Set the time by tilting the left button. Push it and set the temperature by tilting it again.



Step 4 Push the right button to start.

Step 5 When finished. Turn the oven off by pressing and holding the right button for 3 seconds



2

How to cook a frozen pizza?

Step 1 Push the right button to turn the oven on



Step 2 By default, the first function displayed after turning the oven on is the microwave. Tilt the right button until you find the "static" function



Step 3 Set the time by tilting the left button to 10 minutes more than informed on the pizza package to pre-heat the oven. Push it and set the temperature (as informed on the package) by tilting it again.



Step 4 Push the right button to start.

Step 5 After 10 minutes, place the pizza inside



Make sure the container is suitable for use in the oven



HOME

3 How to microwave baby food?

Step 1 Push the right button to turn the oven on



Step 2 Set the time by tilting the left button to 2 minutes. Push it and set the watts (as informed on the package) by tilting it again.



Step 3 Push the right button to start.

Step 4 Stir it with a spoon, check the temperature and repeat the previous steps, if needed.



Make sure the container is suitable for use in the oven



HOME

4 ❄️ How to defrost food?

Step 1 Push the right button to turn the oven on



Step 2 By default, the first function displayed after turning the oven on is the microwave. Tilt the right button until you find the "defrost by weight" function



Step 3 Tilt again to select the type of food to defrost.

Step 4 Tilt the left button to select weight (in grams) of the food to defrost. (see below the set recommendations)



Step 5 Push the right button to start.

dE	Type	Weight (g)	Time (min)
	Meat	500	120
	Fish	300	55
	Fruit	300	35
	Bread	300	25



HOME


 MEAT

Pr	Subcategory	Weight (g)	Level	Function	Temperature (°C)	Time (minutes)
01	Roast beef (medium)	1300	2		200	56
02	Roast pork	800	2		190	88
03	Lamb (medium)	2000	2		190	105
04	Veal	1000	2		190	80
05	Whole roast chicken	1000	2		200	80

 FISH

Pr	Subcategory	Weight (g)	Level	Function	Temperature (°C)	Time (minutes)
06	Fresh fish (whole)	500	2		160	35
07	Frozen fish	600	2		160	50

 VEGETABLES

Pr	Subcategory	Weight (g)	Level	Function	Temperature (°C)	Time (minutes)
08	Mixed grilled	500	4	----	250	15 + 8 ⁽¹⁾
09	Roasted	1000	2		200	33
10	Roasted potatoes	1000	2		200	30

[Next page](#) >



HOME



BREAD - PIZZA - PASTA

Pr	Subcategory	Weight (g)	Level	Function	Temperature (°C)	Time (minutes)
14	Leavened bread (loaf)	1000	2		200	27
15	Pan baked pizza	1000	2		280	12
16	Stone baked pizza	500	1		280	7
17	Pasta bake	2000	1		220	35
18	Lasagne	2000	1		230	40
19	Paella	500	2		190	25
20	Quiche	1000	1		200	40



DESSERTS/PASTRIES

Pr	Subcategory	Weight (g)	Level	Function	Temperature (°C)	Time (minutes)
11	Biscuits	500	2		160	23
12	Muffins	500	2		160	21
13	Tart	1000	2		170	43

[← Previous page](#)



HOME